



## HALLOWEEN PUMPKIN CARVING SET

**GB CY**  
**HALLOWEEN PUMPKIN CARVING SET**  
Operating and safety information

**RO**  
**SET PENTRU SCULPTAT DOVLECI**  
Indicații de operare și siguranță

**DE AT CH**  
**KÜRBIS-SCHNITZSET**  
Bedienungs- und Sicherheitshinweise

IAN 458971\_2401





**citygate24 GmbH**  
Alstädter Straße 8  
20095 Hamburg  
GERMANY

06/2024

Model No.: 1183-11



10/2024



GB CY

## Halloween Pumpkin Carving Kit

### ● Introduction

**i** Congratulations on the purchase of your new product. You have chosen a high-quality product. Please read these operating instructions thoroughly and carefully. These instructions are an essential part of the product and contain important information on first-time use and handling. Always observe all safety instructions. If you have any questions or are unsure how to operate the product, please contact your retailer or service centre. Please keep this manual in a safe place and pass it on to third parties where necessary.

### ● Explanation of symbols

- i** Read the operating instructions!
- 📄** Issue date of user instructions (month/year)
- 📅** Date of manufacture (month/year)
- ⎓** Direct current
- ⚠️** Risk of fatal injury and accidents for infants and children!
- 👤** Observe warning notices and safety instructions!
- 💣** Explosion hazard!
- 🧤** Wear protective gloves!
- ⚡** This symbol indicates that the product operates with safety extra-low voltage (SELV / PELV, protection class III).
- 🏠** Suitable for indoor use only
- 🔋** 1x CR2032 battery included in delivery
- 🔋** Battery included
- ⚠️** WARNING: Contains coin/button battery. Hazardous if swallowed – see instructions.

- 🚫** Keep out of reach of children
- 🚫** Do not use violence!
- 🚫** Never use different systems, brands and types at the same time!
- ⚠️** Do not insert the wrong way round, observe polarity (+ / -)!
- 🚫** Do not throw into the fire!
- 🚫** Do not throw it into the water!
- ⚠️** Do not short-circuit! Batteries can explode or leak.
- ⚠️** Never mix new and used batteries!
- ⚠️** Do not recharge!
- ⚠️** Do not disassemble / open!
- ♻️** Dispose of packaging and product in an environmentally friendly manner!
- ♻️** Risk of environmental damage from incorrect disposal of (rechargeable) batteries!
- 🌳** Packaging made of FSC-certified wood mix

**CE** With the CE label, the manufacturer confirms that this product complies with the applicable European directives.

### ● Intended use

Not suitable for children under 12 years. This product is only suitable for decorative purposes. This product is intended exclusively for indoor use in dry and enclosed spaces. The LED decorative tea light must not be placed inside the pumpkin when it is not in an enclosed space. The product is not suitable for general indoor lighting in the home or for commercial use. This product is intended for use in private households only. Any type of use other than that described above or any modification of the product is prohibited and likely to cause damage or even personal injury. The manufacturer or retailer accepts no liability for loss or damage that occurs as a result of improper or incorrect use.

### ● Included in package

- 1x LED decorative tea light
- 1x pumpkin scraper
- 1x large saw
- 1x small saw
- 1x pen
- 1x battery (CR2032)
- 6x carving templates
- 1x user instructions

### ● Description of parts

- |                            |                     |
|----------------------------|---------------------|
| 1 LED decorative tea light | 5 Pumpkin scraper   |
| 2 Pen                      | 6 Carving templates |
| 3 Small saw                | 7 Battery           |
| 4 Large saw                | 8 On/Off switch     |

### ● Technical specifications

Model number: 1183-11  
Input: 1 x CR 2032, 3 V  $\text{---}$ , 0,08 W  
Protection class: III  
Light colour: warm white

**Battery manufacturer:**  
Name: SUZHOU XINLVZHOU ELECTRONICS CO., LTD.  
Address: SHANJI ROAD 158, XIANGCHENG DISTRICT, SUZHOU CITY, JIANGSU, CHINA.  
Trade name: WARRIORS CR2032 3V LITHIUM CELL  
www.lvzhoudianzi.com.cn  
E-mail: 593221152@qq.com  
Contact: Qiankeyun

### ● Safety instructions

- ⚠️ Safety instructions**
- ⚠️ WARNING!**  
**RISK OF FATAL INJURY AND ACCIDENTS TO INFANTS AND CHILDREN!** Never leave children unsupervised with the packaging material. There is a danger of suffocation from the packaging material. Children often underestimate the dangers. Always keep children away from the product.
  - **Caution!** Only for use under adult supervision.
  - **Caution!** Keep tools out of reach of children after use.
  - Cleaning and battery replacement may not be carried out by children.
  - Keep the product away from children until you have removed the protective strip from the battery compartment.
  - Do not use the product if you notice any defects.
  - Protect the product from sharp edges, mechanical stress and hot surfaces.
  - Do not immerse the product in water or any other liquids.
  - The LEDs can be replaced by specialised personnel.

### ⚠️ Safety Instructions for (Rechargeable) Batteries

- **RISK OF FATAL INJURY!** Keep (rechargeable) batteries out of the reach of children. If swallowed, seek medical advice immediately!
- **EXPLOSION HAZARD!** Never recharge non-rechargeable batteries. Do not short-circuit or open (rechargeable) batteries. They could overheat, cause a fire or explode.
- Never throw (rechargeable) batteries into fire or water.
- Do not expose (rechargeable) batteries to mechanical stress.
- Do not use different battery types or use new and used batteries together.
- Insert the supplied batteries into the product, taking care to ensure correct polarity.
- Do not short-circuit the terminals!
- Remove empty batteries from the product.
- **Caution!** This product contains a coin battery (button cell containing lithium). Coin batteries can cause severe internal chemical burn injuries when swallowed.
- **Caution!** Dispose of spent batteries immediately. Keep the batteries out of reach of children! If a battery is swallowed, seek medical advice immediately.

### ● Risk of (rechargeable) batteries leaking

- Avoid exposing (rechargeable) batteries to extreme conditions and temperatures, e.g. radiators or direct sunlight.
- Avoid contact with skin, eyes and mucous membranes! In the event of skin contact with battery acid, rinse the affected area immediately with plenty of clean water and seek medical advice immediately!
- **WEAR PROTECTIVE GLOVES!** Leaking or damaged (rechargeable) batteries can cause chemical burns if they come into contact with skin. Therefore, wear suitable protective gloves in such cases.
- In the event that a battery leaks, remove it from the product immediately to avoid damage.

### ● Setup

- Instructions:** Take the product out of its packaging and remove all packing material.
- Check that all package contents are present.
  - Check if the product or individual parts are damaged. If that is the case, do not use the product. Please contact the retailer via the service address indicated on the warranty card.
  - Keep the product away from children until you have removed the protective strip from the battery compartment.
  - The batteries supplied are already inserted into the product and fitted with an isolator strip. Remove this plastic strip to start using the product.

### ● Inserting/replacing the batteries

- **⚠️ RISK OF FATAL INJURY!** Please note that the batteries must only be replaced by adults. Ensure that the battery compartment is firmly closed. Batteries can be lethal when swallowed!
  - The battery compartment is located on the bottom of the LED decorative tea light **1** (see Fig. B).
  - Undo the screws to open the battery compartment and remove the discharged battery.
  - Now insert a new battery (CR2032).
  - **Please note:** It is essential to pay attention to the correct polarity.
  - Close the battery compartment lid and retasten the screws to seal it.

### ● Operation

- **CAUTION!** Never leave children unsupervised when using the product! Only for use under adult supervision.  
LED decorative tea light: The ON/OFF **8** switch is located on the bottom of the LED decorative tea light **1** (see Fig. B). Push the switch to the ON position to switch the product on. The flame will now illuminate with a natural flickering effect. Push the switch to the OFF position to switch the product off.
- **CAUTION!** Once the LED light or the LED decorative tea light has been placed inside the pumpkin, the pumpkin is no longer suitable for consumption. Pumpkin scraper: The pumpkin scraper **5** (see Fig. A) is designed for removing the flesh and seeds from inside the pumpkin.  
Small saw / Large saw: You can use the saws **3** / **4** (see Fig. A) for precise carving.  
Pen: You can use the pen **2** (see Fig. A) to transfer the carving template patterns onto the pumpkin.
- **CAUTION!** Once you have drawn on the pumpkin with the pen, the pumpkin is no longer suitable for consumption. Carving templates: The carving templates **6** make it easier to design the pumpkin.

### ● Cleaning and storage

- Do not immerse the LED decorative tea light in water. Make sure that no water gets into the casing.
- Use only a dry, lint-free cloth for cleaning. If the product is very dirty, dampen the cloth slightly.
- When the product is not in use, store inside the packaging in a dry place.
- You can clean the carving tools **3** / **4** / **5** under running water. Do not use any aggressive cleaning agents.

### ● Troubleshooting

- = Fault
- = Cause
- = Solution
- = The LED decorative tea light **1** is not switching on.
- = The product is switched off.
- = Turn the product on (see section "Operation")
- = The batteries are discharged.
- = Replace the batteries (see "Replacing the batteries").

### ● Disposal

- ♻️ Note the labels on the packaging materials when sorting the waste; they are marked with abbreviations (a) and numbers (b) with the following meanings:  
1-7: Plastics  
20-22: Paper and cardboard  
80-98: Composite materials
- 🗑️ You can find out how to dispose of the used product by contacting your local district or city council.
- ♻️ In the interest of environmental protection, when the product has reached the end of its useful life, do not dispose of it as general household waste but have it properly recycled. For information on recycling centres and their opening times, please contact your local council.

Faulty or used batteries must be recycled in accordance with Directive 2006/66/EC and its amendments. Return batteries and/or the product to the local recycling facilities provided.

**♻️ Risk of environmental damage from incorrect disposal of rechargeable batteries!**  
Batteries must not be disposed of as general household waste. They may contain toxic heavy metals\* and are subject to special waste

treatment. Batteries and rechargeable batteries that are not permanently fixed inside the product must be removed before disposal of the product and disposed of separately. Please ensure batteries/rechargeable batteries are fully discharged when disposed of! Wherever possible, use rechargeable batteries rather than single-use batteries.  
\*) Marked as followed: Cd = cadmium, Hg = mercury, Pb = lead

### ● Warranty

Dear customer, This product comes with a 3-year warranty from the date of purchase. In the event that this product is faulty, you have legal rights against the seller of the product. These statutory rights are not restricted by our warranty as set out below.

#### Warranty terms

The warranty period begins with the date of purchase. Please keep the original receipt in a safe place. It is required as proof of purchase. If a material or manufacturing defect occurs within three years of the date of purchase, we will repair or replace the product for you free of charge, or refund the purchase price, at our discretion. This warranty service is granted provided that the faulty device and the proof of purchase (receipt) are presented within three years, along with a brief written description of the fault and of when it occurred. If the fault is covered by our warranty, we will return the fixed product or send you a new one. No new warranty period shall begin upon repair or replacement of the product.

#### Warranty period and statutory warranty claims

The warranty period is not renewed after a warranty service has been granted. This rule shall also apply for any replaced or repaired parts. Any damage or faults that already existed when buying the product must be reported immediately upon unpacking the product. A fee is charged for any repairs that are carried out after the end of the warranty period.

#### Warranty scope

The device was carefully manufactured according to the strictest quality guidelines and thoroughly tested before delivery. The warranty covers material and manufacturing defects as well as the battery. This warranty does not apply to product parts that are subject to normal wear and tear and can thus be regarded as wearing parts; nor does it cover damage to fragile parts, such as switches or parts made of glass. This warranty is void if the product has been damaged, improperly used or serviced. To ensure proper use, all instructions included in the manual must be followed carefully. All uses and actions that users are discouraged from or warned of in the manual must be avoided under all circumstances. The product is intended for private household use only, and not for commercial activities. The warranty is void, if the product is treated inappropriately, if force is applied, and in the case of any manipulation that is not carried out by our authorised service branch.

#### Warranty processing

- To ensure your request is handled swiftly, please observe the following **Notes:**
- Please have the receipt and the article number (e.g. IAN 123456) ready as proof of purchase for all enquiries.
  - Please refer to the type plate on the product, an engraving on the product, the cover of the manual (bottom left) or the sticker on the back or base of the product to find out the product number.
  - In the case of any malfunctions or other defects, please call or email the service department indicated below as a first step.
  - After your product has been registered as faulty, you can send it to the specified service address, free of charge. Please include the proof of purchase (receipt) and information about the defect and about when it occurred.

### ● Service

**GB**  
Service Great Britain  
Tel.: 00800 80040044  
E-Mail: administration@mynetsend.de

**CY**  
Service Cyprus  
Tel. : 00800 80040044  
E-Mail: administration@mynetsend.de

**IAN 458971\_2401**

Please have the receipt and the article number (e.g. IAN 123456) ready as proof of purchase for all enquiries.

You can find an up-to-date version of the operating instructions at: www.citygate24.de

You can download this and many other manuals, product videos and installation software at **www.lidl-service.com**. Scanning the QR code on the front page will take you directly to the Lidl Service web page (www.lidl-service.com) where you can access the user instructions by entering the item number (IAN) 123456\_7890.

RO

## Set pentru sculptat dovleci

### ● Introducere

**i** Vă felicităm pentru achiziționarea noului dumneavoastră produs. Ați luat decizia de a cumpăra un produs de mare valoare. Vă rugăm să citiți cu atenție și în întregime acest manual de utilizare. Acest manual aparține produsului și conține indicații importante pentru punerea în funcțiune și manipularea acestuia. Vă rugăm să acordați atenție deosebită tuturor indicațiilor de siguranță. Dacă aveți întrebări sau nu sunteți sigur cu privire la manipularea produsului, vă rugăm să vă adresați distribuitorului dumneavoastră sau atelierului de servicii din proximitatea dumneavoastră. Vă rugăm să păstrați cu grijă acest manual și să îl transmiteți terților dacă situația o impune.

### ● Explicația desenelor

- i** Citiți manualul de utilizare!
- 📄** Data emiterii manualului de utilizare (lună/an)
- 📅** Data producerii (luna/an)
- ⎓** Tensiune constantă
- ⚠️** Pericol de accidentare și de deces pentru copii!
- 👤** Respectați indicațiile de siguranță și avertismentele!
- 💣** Pericol de explozie!
- 🧤** Purtați mănuși de protecție!
- ⚡** Acest simbol indică faptul că produsul funcționează cu tensiune mică de protecție (SELV/PELV) (clasa de protecție III).
- 🏠** Adecvat doar pentru spații interioare
- 🔋** Baterii 1x CR2032 incluse
- 🔋** Baterie inclusă  
INDICAȚIE DE AVERTIZARE: Conține o baterie tip buton. Aceasta este dăunătoare pentru sănătate în cazul în care este înghițită – a se vedea instrucțiunile.
- 🚫** A nu se păstra la îndemâna copiilor
- 🚫** Nu folosiți violent!
- 🚫** Nu folosiți niciodată sisteme, mărci și tipuri diferite în același timp!
- 🚫** Nu inserați invers, respectați polaritatea (+ / -)!
- 🚫** Nu aruncați în foc!

- 🚫** Nu!l aruncați în apă!
- 💣** Nu scurtcircuitați! - Bateriile pot să explodeze sau să curgă.
- 🏠** Nu amestecați niciodată bateriile noi cu cele uzate!
- 🔋** Nu reincărcați!
- ⚠️** Nu dezasamblați / deschideți!
- ♻️** Eliminați ambalajul și produsul într-un mod ecologic!
- ♻️** Daune aduse mediului înconjurător prin eliminarea necorespunzătoare a bateriilor/acumulatorilor!
- 🌳** Ambalaj din mix de lemn certificat FSC

**CE** Prin marcajul CE producătorul confirmă că acest produs corespunde directivelor europene în vigoare.

### ● Destinația utilizării

Adecvat doar pentru copii mai mari de 12 ani. Acest produs este conceput exclusiv pentru utilizarea în spații interioare uscate și închise. Lumânarea pastilă decorativă cu LED nu trebuie să fie plasată în dovecac dacă aceasta nu se află în spații închise. Produsul nu este adecvat pentru iluminarea încăperilor în gospodărie și nici pentru utilizarea comercială. Acest produs este prevăzut doar pentru utilizarea în gospodării private. O altă utilizare decât cea descrisă anterior sau o modificare a produsului nu este permisă și poate duce la deteriorarea sa sau chiar la vătămări corporale. Producătorul sau distribuitorul nu își asumă responsabilitatea pentru daune care intervin ca urmare a utilizării necorespunzătoare sau greșite.

### ● Furnitura

- 1x lumânare pastilă decorativă cu LED
- 1x racletă pentru dovecac
- 1x ferăstrău mare
- 1x ferăstrău mic
- 1x creion
- 1x baterie (CR2032)
- 6x modele de sculptat
- 1x manual de utilizare

### ● Descrierea componentelor

- |                                      |                            |
|--------------------------------------|----------------------------|
| 1 lumânare pastilă decorativă cu LED | 5 racletă pentru dovecac   |
| 2 creion                             | 6 modele de sculptat       |
| 3 ferăstrău mic                      | 7 baterii                  |
| 4 ferăstrău mare                     | 8 Întreprător PORNIȚ/OPRIȚ |

### ● Date tehnice

Număr model: 1183-11  
Intrare: 1 x CR 2032, 3 V  $\text{---}$ , 0,08 W  
Clasă de protecție: III  
Culoare lumină: alb cald

**Producător de baterii:**  
Numele: SUZHOU XINLVZHOU ELECTRONICS CO., LTD.  
Adresa: SHANJI ROAD 158, XIANGCHENG DISTRICT, SUZHOU CITY, JIANGSU, CHINA.  
Marca: WARRIORS CR2032 3V LITHIUM CELL  
www.lvzhoudianzi.com.cn  
E-mail: 593221152@qq.com  
Contact: Qiankeyun

### ● Indicații de siguranță

- ⚠️ Indicații de siguranță**
- 👤 AVERTISMENT!**
- PERICOL DE ACCIDENTARE ȘI DE DECES PENTRU COPIII** Nu lăsați niciodată ambalajul la îndemâna copiilor nesupravegheați. Există pericol de sufocare din cauza materialelor de ambalare. Copiii subestimează adesea pericolele. Nu lăsați produsul niciodată la îndemâna copiilor.
  - **Atenție!** A se utiliza doar sub supravegherea adulților.
  - **Atenție!** Nu depozitați uneltele la îndemâna copiilor după folosire.

- Curățați produsului și înlocuirea bateriilor nu se vor efectua de către copii.
- Produsul nu trebuie lăsat la îndemâna copiilor până când nu este îndepărtată banda de protecție din compartimentul cu baterii.
- Începăți utilizarea produsului, dacă observați orice fel de defecțiune.
- Protejați produsul de mouchii ascuțite, sarcini mecanice și suprafețe fierbinți.
- Nu scufundați produsul în apă sau în alte lichide.
- LED-urile pot fi înlocuite de către personal specializat.

### ⚠️ Indicații de siguranță pentru baterii/acumulatori

- **PERICOL DE DECES!** Nu lăsați bateriile/acumulatorii la îndemâna copiilor. În caz de înghițire accidentală, adresați-vă imediat unui medic!
- **PERICOL DE EXPLOZIE!** Nu reincărcăți niciodată bateriile care nu sunt reincărcabile. Nu scurtcircuitați bateriile/acumulatorii și nu încercați să le deschideți. Urmările acestor acțiuni pot fi supraîncălzirea, pericolul de incendiu sau pericolul de explozie.
- Nu aruncați niciodată bateriile/acumulatorii în foc sau apă.
- Nu supuneți bateriile/acumulatorii sarcinilor mecanice.
- A nu se utiliza tipuri diferite de baterii sau a nu se combina baterii noi cu unele consumate.
- Introduceți bateriile conform polarității în produs.
- Nu scurtcircuitați bornele!
- Îndepărtați bateriile consumate din produs.
- **Atenție!** Atenție! Acest produs conține o baterie tip pastilă (buton cu litiu). În cazul înghițirii o baterie tip pastilă poate cauza arsuri chimice grave.
- **Atenție!** Eliminați bateriile uzate în mod corespunzător. Nu lăsați bateriile la îndemâna copiilor! În cazul înghițirii unei baterii solicitați neîntârziat ajutorul unui medic.

### ● Risc de scurgere al bateriilor/acumulatorilor

- Evitați condițiile extreme și temperaturile care pot afecta bateriile/acumulatorii, de ex. radiatoarele/lumina directă a razelor solare.
- Evitați contactul cu pielea, ochii sau mucoasa nazală! În caz de contact cu acidul scurs din baterii, spălați imediat zona afectată cu apă limpede din abundență și adresați-vă de îndată unui medic!
- **PURTAȚI MĂNUȘI DE PROTEȚIE!** Scurgerea bateriilor/acumulatorilor defecți poate provoca arsuri la contactul cu pielea. Din acest motiv, vă rugăm să purtați mănuși de protecție.
- În caz de scurgere a bateriilor, îndepărtați-le imediat din produs pentru a evita eventualele defecțiuni.

### ● Punerea în funcțiune

- Indicație:** scoateți produsul din ambalaj și îndepărtați toate materialele de ambalare.
- Verificați integritatea furniturii.
  - Verificați dacă produsul sau componentele individuale prezintă deteriorări. Dacă faceți o astfel de constatare nu folosiți produsul. Adresați-vă companiei care a introdus pe piață produsul la adresa de service menționată pe cardul de garanție.
  - Produsul nu trebuie lăsat la îndemâna copiilor până când nu este îndepărtată banda de protecție din compartimentul cu baterii.
  - Bateriile furnizate sunt deja introduse în produs și sunt prevăzute cu o bandă de protecție. Îndepărtați banda pentru a pune produsul în funcțiune.



